SPECIFICATION

XEAST®

□□ □ □□□ □□ □□ XE-608

Specification parameter	Measuring range	Precision
DC voltage	9.999mV/99.99mV/999.9mV/9.999V/99.99V/999.9V	±(0.5%+3)
AC voltage	9.999mV/99.99mV/999.9mV/9.999V/99.99V/750.0V	±(1.0%+3)
DC voltage	99.99uA/999.9uA	±(0.8%+3)
	999.9mA/9.999A	±(1.0%+3)
AC voltage	99.99uA/999.9uA	±(1.0%+3)
	999.9mA/9.999A	±(1.2%+3)
Resistance	99.99Ω	±(1.0%+3)
	999.9Ω/9.99KΩ/99.99KΩ/999.9KΩ	±(0.5%+3)
	9.999MΩ	±(1.5%+3)
	99.99MΩ	±(3.0%+3)
Capacitance	9.999nF	±(5.0%+20)
	99.99nF/999.9nF/9.999uF/99.99uF/999.9uF	±(2.0%+5)
	9.999mF	±(5.0%+5)
Frequency	99.99Hz/999.9Hz/9.999kHz/99.99kHz	±(0.1%+2)
	999.9kHz/9.999MHz	
Duty Cycle	1%-99%	±(0.1%+2)
Measuring Temperature Range	-20°C~1000°C/-4°F~1832°F	±(2.5%+5)
Diode Test	Yes	
Features		
Auto range / manual range	True RMS	Date hold
Backlit display	Low battery prompt	auto power-off
Relative value measurement		

PRODUCT PICTURES

XEAST®

□□□ XE-608□ LCD □□□ □□ □□□ □□ □□□ □□

XEAST®

XEAST® XE-608
9999 COUNTS
AUTO MANU
HOLD PEAK
DC
AC
T-RMS
DCA/ACA
>2S POWER
HOLD
>2S REL
AUTO POWER OFF
NCV
RANGE
Hz%
A mA
TRUE RMS
FUSED
10A MAX
COM
FUSED
200mA MAX
600V CAT III
1000V CAT II
µA

XEAST®

XEAST® XE-608
9999 COUNTS
AUTO MANU Δ
HOLD PEAK MAX MIN
DC
AC
T-RMS
DC/AC/CA
>2S POWER
HOLD
>2S REL
AUTO POWER OFF
RANGE
A mA
TRUE RMS
COM
VΩHz
μA

● APPLICATIONS

XEAST®

□□□ □□ □□ XE-608□ □□ □□

Analog bar graph

BUTTON DESIGN Vs ROTARY DESIGN

- 1.Buttotn design,one-handed operation,faster and high efficiency working.
- 100,000 times efficient testing,still work perfect and unaffected by harsh environment.

- Tranditional rotary design,need two-handed operation,effect working efficiency.
- Contact plate is easy get rusty and resulting in poor connecting in wet environment.

ZT-X THERMOCOUPLE **Vs** OTHER THERMOCOUPLES

▲High quality flexible temperature probe

Panel Introduction

Accurate Measurement , True Reflection

The new desigh button multimeter has a mini size and complete functions

Measure ° C / ° F

Celsius and Fahrenheit display simultaneously

Voltage measurement

Voltage (V) and Frequency(Hz) display simultaneously .

Automatic switch to current testing

Tranditional multimeter must switch to current mode then measure current,ZT-X can automatically switch to current mode when plug in test leads.

▲ Before inserting the pen

▲ After the insertion of the pen

Tips

When the test leads are inserted into or , some functions are shielded. Then the voltage will change to current automatically.

When the test leads are inserted into all functions can measure normally.

Resistance Minimum measurement range 0.01Ω.

Package Include

XEAST®

□□□ □□ □□ XE-608 □□□

Terms of Trade

XEAST®

□□ □□

1). □□ □□:
□□□ T / T, L / C, Paypal, MoneyGram □ Western Union□ □□□□□.
□□ □□ 30 % □□□ □ □□ 70 % □□.
2). □□ □□ :
□□□ □□□□□ □□ □□ □ □□□ □□ □□□ □□ □□□□□. □□ oftern □□ □□□□□ (DHL, TNT, UPS, □□□ □□□□□, EMS, SPSR, 139 □□

□□□ □□), LCL, FCL
□□□ □□ □□□□ □□ □□ □ □□□, □□□ □□□ □□ □ □□ □□□ □□ □□□ □□□ □ □□□.

COMPANY INFORMATIONS

XEAST®