XEAST 120M Camera Newest Digital Laser Distance Meter Rangefinder

SPECIFICATION

XEAST®

Working Range:	120m
Smallest unit displayed:	1mm
Measuring accuracy:	±2mm**
Laser:	class Ⅱ, <1 mW
laser wavelength:	635nm
Continuous distance measuring(tracking):	√
Area / volume:	√
Pythagoras measring:	√
Length/Area/volume Addition/Subtraction:	√
MIN/MAX value：	√
Delay Measurement:	√
Skating-out:	√
Delay Measurement:	√
Self-Calibration:	√
Angle of Tilt:	±90°
Multi-direction Electronic level Bubble:	√
Backlight:	√
Record:	100pcs
USB Connector:	√
Auto Laser off:	20~120s
Auto Switch off:	100~300s
Storage temperature range:	-20~60℃
Working range:	0~40℃
Storage Humidity:	RH85%
Power supply:	Ni-mh 3x1.2V 800mAh
Dimensions:	125*54*27mm

SNDWAY®
SW-S120
41.6°
7.487 m
6.259 m
6.598 m
7.405 m
Laser Distance Meter
0.05m
120m
READ
MENU
OFF
CLEAR

SNDWAY®
SW-S120
Laser Distance Meter
120m
0.05m
READ
MENU
OFF
CLEAR

READ
MENU
UNIT

0.769 m
0.446 m
4.520 m
0.7°

P ≤1mw λ =635nm
Battery: 3 x 1.2V AAA Ni-MH
Class II Laser
Product
AAA
AAA
AAA

Product Paramters

Camera measurement

Operation:Short press button

Purpose:In this mode the exact measured point can de located on the LCD display

What you see is

What you get

Angle Measurement

Angle value shows on the top o the screen

the range of angle is -90.0°~90.0°

Two Unita of Angle:°and%(Slope)

Vertical Angle

Singe Measurement

Operation:Short press button

Continous Measurement

Operation: Long press button READ

Maximum and Minimum value will be shown on the screen.

Present result display in major

The usea can use this mode to find the target distance without frequent operation

Area Measurement

Operation:Press button , shows on the scren,

Please follow the below instrections for area measuring



S=LxW

Volume Measurement



V=L x W x H

Operation: Shora press button twice,screen showa

Please folllow the below instruction for erea measuring

Addition/Subtraction

Length Add/subtracy

Area Add/Subtract

Volume Add/Subtract

Pressed the keys for a short time into add test when the LCD display"+"

Pressed the keye for a long time into add test when the LCD display"_"

The Pythagorean theorem

There are six triangnle measurement methods:



Multi-direction Electronic Level Bubble

Long press buton ,screen shows:

Level Angle

Vertical Angle

Press button OFF CLEAR to exit



Length measurement

Area measurement

Volume measurement

Packing list

TERMS OF TRADE

1). Terms of Payment:
We accept T/T, L/C,Paypal,MoneyGram and Western Union.
30% deposit and other 70% balance before shipment.
2). Terms of Shipping:
It depends on clients order quantity and your special request.We oftern adopt Express(DHL, TNT,UPS,FEDEX ,EMS,SPSR,139 express and so on),LCL,FCL .
Items will be careful checking before shipment,and we will update the delivery status timely after the goods are sent out.

COMPANY INFORMATIONS

SALES TEAM

XEAST®

Your Testing Partner

WOKRSHOP