





**XEAST<sup>®</sup>**



**XEAST®**



**● APPLICATIONS**

**XEAST®**

XE-608



## Analog bar graph



### BUTTON DESIGN

# VS

### ROTARY DESIGN



- 1. Button design, one-handed operation, faster and high efficiency working.
- 100,000 times efficient testing, still work perfect and unaffected by harsh environment.

- Traditional rotary design, need two-handed operation, effect working efficiency.
- Contact plate is easy get rusty and resulting in poor connecting in wet environment.





## Measure °C / °F

Celsius and Fahrenheit display simultaneously



## Voltage measurement

Voltage (V) and Frequency(Hz) display simultaneously .



## Automatic switch to current testing

Traditional multimeter must switch to current mode then measure current,ZT-X can automatically switch to current mode when plug in test leads.





▲ Before inserting the pen



▲ After the insertion of the pen

### 🔔 Tips

When the test leads are inserted into  or , some functions are shielded. Then the voltage will change to current automatically.

When the test leads are inserted into  all functions can measure normally.

### Test NCV


Non-contact voltage detection





# Resistance

Minimum measurement range 0.01Ω.







● COMPANY INFORMATIONS

